

Customer care : From 9 am to 6 pm, we are at your disposal for service gas analyzer / software / computer / maintenance and calibration.

Chromatotec Bulletin

Issue – February 2006

SUMMARY

Exhibitions 2006	p1
Involvement in the Middle East	p1
airTOXIC PID BTEX performance	p1
European certification	p1
Protection of your process and catalysers	p1
Explosion proof cabinet	p2
Sulfur control with our airmoQuality	p2
Application in the screening building	p2
Application in refineries	p2
Automation modules	p2

Involvement in the Middle East

As a **key market** for the future of our group, our goal, today, is to **develop our market shares** in the whole Middle East with **exhibitions and local support**.

Exhibitions: After our participation to the Environment 2005 Fair in Abu Dhabi, we now exhibit at the **Arab Lab Fair in Dubai** from 13th to 16th February 2006.

Sales in the ambient air market:
In the Middle East, we are present in **several countries**.
Air polluting monitoring has been running now since several years.

Ask us to know our distributors

EXHIBITIONS 2006

ANALYSE INDUSTRIELLE – PARIS-LA DEFENSE
31 January – 2 February 2006
<http://www.mci-salons.fr/ai>

ARAB LAB – DUBAI
13 – 16 February 2006
<http://www.arablab.com>

ACHEMA – FRANKFURT
15 – 19 May 2006 – Booth 10.1K41
<http://www.achema.de>

AWMA – NEW ORLEANS
20 – 22 June 2006 – Booth 325
<http://www.awma.org>

GTI – HOUSTON
July 2006
<http://www.Gastechnology.org>

airTOXIC PID BTEX Performances

- ✚ Measurement of Benzene, Toluene, Ethyl – Benzene, o-m-p Xylene (BTEX)
- ✚ PID detector
- ✚ In-built computer
- ✚ N2 only used
- ✚ Self cleaning of the lamp

Purpose:

- Monitoring air quality for **ambient air networks**
- Monitoring the pollution compounds in an **industrial environment**

Results:

- **Accurate sensitivity** and better follow up of the polluting compounds
 - **Modbus communication** protocol enables to centralize the information
 - A **multiplexer and alarm pilot system** allows to identify easily the polluting compounds
 - **Internal calibration** tube allows to analyze with a standard


ARAB LAB
The Expo 2006
The International Show for Tomorrow's Technology

Visit our booth # 327 Hall 8

NEWS

European certification

In January 2006 the **airTOXIC PID analyzer** has received the accreditation for the analysis of 5 products B T E X by a European organization dedicated to Research Development, according the **directive 69/2000**.



We recall that the analyzer **airmoBTX 1000**, with its FID detector system, is the only instrument that received the DIN 33963 norm parts I & II in 1996 approved by the TÜV laboratory for the analysis of BTEX.

Protection of process and catalysers

Known as analyzer for the **detection of sulfur compounds** for gas odorization companies, our analyzer, **EnergyMEDOR ppb**, can also analyze the sulfur compounds before and after the purification system. **Sulfur compounds** at ppm or ppb level destroy catalysers

Send your inquiry to info@chromatotec.com

Send us your emails to receive our News every two months

Explosion proof cabinet

In a partnership with companies specialized in the manufacturing of **Ex p cabinet**, we can propose you to install our **CHROMA** (*detection of impurities in gas or air*)-or our **MEDOR** (*detection of sulfur compounds in gas or air*) **analyzers in a ex Hazardous areas** with applications in the chemical, petrochemical, process industries.

For Example

Application: natural gas plant

On-line analysis in hazardous area of THT with our THTMEDOR Application in a gas natural plant of an THTMEDOR



THTMEDOR in a ex P cabinet in South Korea

Specific Sulfur Control with our airmoQuality

The cabinet allows the operation from **sampling to data transfer**. The GC with double flame photometric detector enables to **separate H₂S and COS** as well as to delete any interference with methane. Besides a traceable calibration mixture of **6 sulfur compounds** balanced in **pure methane** is used. The **high signal-to-noise output** makes the monitoring at low / mid ppb levels possible.

This cabinet is well adapted for field installation in accordance with **Ex guidelines**.

CHROMATOTEC

In Europe

15 Rue d'Artiguelongue
33240 SAINT-ANTOINE - FRANCE
Tel : +33 (0)557940626 Fax : +33 (0)557940620

In USA

18333 Egret Bay Suite 270
HOUSTON TX 77058
Tel : +1 281 335 4944-Fax : 1 281 335 4943

H₂S & Mercaptans: application in screening building

Protection in the screening building of **the waste water plant with a H₂S detector to measure sulfurous compounds** (-methyl-mercaptans & H₂S) in ambient air;

process:

- **with a sampling sequencer system**, the intakes lines are setup **to stop the humidity** around the screens reaching the analyzer.
- **With a supervising system and visible and audible alarms**, concentrations compounds can be monitored locally but also externally.



New analyzer for detection of volatile Total Reduced Sulfur compounds in ambient air, TRSmedor

Natural gas analyzer in 7 min ChromENERGY C₁/C₆+

Refinery application:

Our ChromENERGY C₁/C₆+ with its new backflush column and a single valve enables to purge out effectively the C₆+ components of the column and therefore will not influence the analysis of C₁ – C₆; this will allow **to reduce the time analysis considerably**

VistaCHROM news Automations modules



- Statistics calculation
- Calculation of rolling averages
- Filing
- Alarms monitoring
- I/O monitoring
- G/C monitoring (default analyzer)

Send your inquiry to info@chromatotec.com