

## WALL MOUNTED COMPUTER Ref.: XXX023

### Dimensions without connector:

28,5 cm x 14cm

### Dimensions with connectors:

28,5 cm x 19 cm



### Technical specifications:

- Wall-mounted box with power supply 210 volts / 50HZ
- Industrial computer: Type AMD 500Mz 3V3
- Low-energy board and fan
- Ethernet connector: 10-100MHz base T
- Screen connector
- **5 serial ports** compatible with RS232 including one for UPS
- **1 serial port** compatible with RS485
- **4 USB2 ports**
- WINDOWS XP Pro and **Vistachrom**
- Screen , keyboard, mouse not supplied (USB connecteur)

**VISTACHROM** is a powerful software package (wiever/serviceGC/driver/calcul) used for setting-up the instrument (method) and collecting data under Windows.

Data, chromatograms, integration reports, ... are transfered **from the monitor to the computer via RS-232 output** where they can be **displayed on the screen** and **retreated** by **VISTACHROM**.

### The main characteristics of VISTACHROM are:

- **internal process control,**
- **online control** of operational mode,
- method / method batches programming **sequence,**
- data acquisition for real **traceability and online chromatogram display,**
- **time-stamped results**
- chromatography software with **reprocessing of the data by batch,**
- data and profile control (retention time / area / amount / concentration, **trends**),
- internal and external self diagnostics (status of operation and failures with approximately 50 different **error codes**).
- Service GC for maintenance

#### AMERICA

**CHROMATOTEC Inc.**  
1833 Egret Bay Blvd, Suite 270,  
HOUSTON TX 77058 – USA  
Phone: +1 (281) 335 4944  
Fax: +1(281) 335 4943

To contact us:

[info@chromatotec.com](mailto:info@chromatotec.com)

#### EUROPE

**AIRMOTEC ag SA**  
15 rue d'Artiguelongue  
F-33240 SAINT-ANTOINE (BORDEAUX)  
Tel : +33 (0)557 940 626  
Fax : +33 (0)557 940 620

Due to Chromatotec continuing program on product improvements, specifications are subject to change without notice

\\Toutatis\web\marketing\_web\data\_sheets\uk\ltp\_XXX023\_wall\_mounted\_computer\_080312\_w.doc

[www.chromatotec.com](http://www.chromatotec.com)