

airmoVOC C6-C12

BTEX included

Analysis of up to 53 compounds from
C6 to C12 and halogen compounds (TO14) or (PAMS).

Model: A21022Environment:

Urban/Non urban area pollution control
Indoor measurements
BTEX / PAMS / CE analysis
Plant / process emissions



MCERTS
CSA MC130231/06
CSA MC130230/07

Certified

EN 14662-3
EN 15267-1
EN 15267-2
QAL1

SCAN or CLICK ME

Process:

Industrial Hygiene
Fence line monitoring

Other applications:

Wastewater plant, Purge and trap (method 502-2 or
524), Ambient air control (PAMS and TO14)



Selected by US EPA



1996



2006



2010-C212

2010

Chromatotec® is specialised in VOC, Sulfur and permanent gases analysis at trace and ultra trace levels (ppm, ppb, ppt).
Please visit our website for more details.

Naphtalene

CHCL3

Styrene

BTEX

CCL4

Tri-methylbenzene

MTBE

airmoVOC C6-C12

BTEX included

Analysis of up to 53 compounds from
C6 to C12 and halogen compounds (TO14) or (PAMS).



Principle:

The airmoVOC C6-C12 uses a valve with 1 sample trap, and a **metallic capillary column**.

- Miniaturization, sensitivity, mobility and flexibility are its main features.

Everything from the sample port up to the data storage is integrated in a 19"-rack 5U:

- Uninterrupted sampling with pre-concentration on 1 absorbent tube
- Gas chromatograph with 0.2 mm ID metallic column and programmable temperature gradient oven and pressure / flowcontrol of the carrier gas by piezo-valve

Before delivery the analyser is tested for one week by our quality control department. The Vistachrom software enables the user to visualize and store data on a PC. Furthermore it enables the user to recalculate, calibrate the instrument export data and to set-up measurement.

The software allows the calculation of retention time, area, mass or concentration profiles.

**For more information, consult our Case Study
Ambient air monitoring like :
airmoOzone 88, airmoOzone + DET QMS 96 from PAMS-TO14,
Car painting line, airmoTWA, airmoVOC BTEX**

Options:

- On-line results are transmitted via: MODBUS / JBUS or MGS1 communication protocol
- AirmoVOC Expert 1 ppt
- Automatic validation and calibration with internal CALIB
- 24 V power supply
- Hydrogen and zero air generator for transportable analysers
- Multiplexer: 2 to 32
- Purge module to extract VOC from water for online VOC in water analysis
- Internal or external multipoint calibration and zero with CALIB MFC, XXXCYL MFC, airmoCAL MFC or airmoCAL D
- Up to C16 with airmoVOC C6C16

Product technical specifications:

C6 to C12 analysis:

- C6 (Hexane, Dimethylbutane) to C10 (Diethylbenzene, Naphtalene) and dodecane

Detection limit:

- Tri-methylbenzene: 10 ppt or 0.05 µg/m³
- Benzene: 10 ppt in standard
1 ppt with airmoVOC Expert

Detection range:

- 0.05 to 45 µg/m³ for Tri-methylbenzene and Benzene - (A3)
- 0,50 to 400 µg/m³ for Tri-methylbenzene and Benzene - (A2)

Note: Be careful with total mass and mass by compounds.

Amplification 1: On demand to decrease the sampling volume.

Relative Standard Deviation:

- < 0.3 % over 48h (RT)
- < 3 % over 48 h (Conc.)

Results:

- Data storage
- MODBUS / JBUS communication protocol (option)

Cycle time:

- 15 min, 30 min, 40 min, 60 min

Gas supply:

- H2 (FID and carrier gas): 30 ml/min (inlet 2 bars; 1/16" swagelock)
- Air (FID): 180 ml/min (inlet 3 bars ; 1/8" swagelock)
- Sample inlet (vacuum pump) 1/4" swagelock
- Pneumatic valve 90ml/commutation

Sample volume:

- 30 to 700 ml (programmable)
(Sampling time up to 40 minutes)

Power supply:

- Main: 230 V / 115 V or 50 Hz / 60 Hz
- Battery: 24 V (option)

Electrical consumption:

- Mean: 150 VA, Peak 360 VA

Dimensions and weight:

- Rack: 19" - (5U)
- Height: 222 mm
- Width: 482 mm
- Depth: 600 mm
- Net Weight: 22 kg



[CLICK HERE FOR ADDITIONAL DIMENSIONS DETAILS](#)

To order:

airmoVOC C6-C12
5U inbuilt computer
airmoVOC C6-C12 XPERT

Model:

A21022
A23022

Chromatotec® is continuously improving its products, therefore these specifications are subject to change without notice

To contact us: sales@chromatotec.com

NORTH AMERICA
Houston - USA

EUROPE
Bordeaux - FRANCE

ASIA
Beijing - CHINA